

---

---

# FD-211-P Double Density Floppy Disk System

*Users Manual*

**Charles River Data Systems, Inc.**

4 Tech Circle, Natick, MA 01760 Tel. (617) 655-1800 TWX (710) 386-0523

**CARD**

FD-211-P DOUBLE DENSITY  
FLOPPY DISK SYSTEM

Users Manual

CHARLES RIVER DATA SYSTEMS, INC.

---

4 Tech Circle, Natick, Massachusetts 01760

Tel. 617-655-1800

CRDS

The following are trademarks of CHARLES RIVER DATA SYSTEMS, INC.:

FD-211	FC-102
FC-202	FD-11

The following terms used in this manual are trademarks or designations of DIGITAL EQUIPMENT CORPORATION:

RX-11	RX01
PDP-11	RX02
RT-11	
LSI-11	

The material in this manual is for informational purposes and is subject to change without notice.

CHARLES RIVER DATA SYSTEMS, INC. assumes no responsibility for any errors which may appear in this manual.

Copyright © 1979 by CHARLES RIVER DATA SYSTEMS, INC.  
All Rights Reserved

CRDS P/N 97-21306

## TABLE OF CONTENTS

<u>Section</u>	<u>Page</u>
1	INTRODUCTION 1-1
	1.1 System Configuration 1-1
	1.2 Controller Card 1-2
	1.3 FD-211 Dual Drive Chassis 1-2
	1.4 System Compatibility 1-2
	1.5 Media Compatibility 1-2
	1.6 System Specifications 1-7
2	INSTALLATION AND OPERATION 2-1
	2.1 Unpacking 2-1
	2.2 Rack Mounting the FD-211 2-1
	2.3 Electrical Installation 2-3
	2.4 Diskettes 2-6
	2.5 Initial Operation and Check-Out 2-7
	2.6 Switch Controls 2-8
	2.7 Write-Protect Detector 2-8
3	STANDARD INSTRUCTION SET 3-1
	3.1 General 3-1
	3.2 Register and Vector Addresses 3-1
	3.3 FD-211 Register Description 3-1
	3.4 Command Functions and Their Protocol 3-8
4	SPECIAL FUNCTIONS: BOOTSTRAP AND SELF-TEST 4-1
	4.1 Enabling and Disabling the Bootstrap 4-1
	4.2 Using the Bootstrap 4-2
	4.3 Self-Test Function 4-3
5	USE OF THE FD-211 WITH RT-11 5-1
	5.1 Generation of DY-Compatible RT-11 System Disks 5-1
	5.2 Creating a DY-Based System on a DX-Based System 5-1
	5.3 Creating a DY-Based Double Density System Diskette 5-3
	5.4 Using the Format Command Under RT-11 5-3
6	UPDATING FD-11 SYSTEMS TO DOUBLE DENSITY DMA OPERATION 6-1
	6.1 Installation 6-1
	6.2 Use of the FD-211-U-P 6-2
7	MAINTENANCE 7-1
	7.1 Preventive Maintenance 7-1
	7.2 Diagnosing the Problem 7-2
	RETURNING MATERIAL
	WARRANTY

Section 1  
INTRODUCTION

This manual contains all the information necessary to install and operate the FD211-P flexible disk system. Section 2 contains information on unpacking, installation and diskette care. It should be read carefully before any use of the unit is attempted.

The FD211-P is a dual density flexible disk system compatible with Digital Equipment Corporation's PDP-11 computer family. The "P" designation indicates a Unibus interface rather than the FD211 which is another CRDS product which is compatible with the LSI-11 Q-Bus. The only difference between the FD211 and FD211-P is in the controller card. The dual drive chassis is identical in both products. For this reason, the "P" designation does not appear on the serial tag on the rear of the FD211 unit. For the purposes of this manual the designation FD211 will be used to refer to the FD211-P product throughout the manual. The FD211 is a direct replacement for Digital's RX21 (the PDP-11 version of the RX02) disk system. It provides diskette as well as single density capability. The single density mode allows access to programs written on older single density systems as well as an industry standard format to exchange data with other systems.

1.1 SYSTEM CONFIGURATION

All FD211 Systems are shipped with the following parts:

- 1 Controller and Formatter Card for PDP-11 (FC-102)
- 1 Dual Drive Chassis
- 1 Chassis Slides and Mounting Hardware
- 1 A/C Power Cord
- 1 FD-211-P User Guide

The controller/formatter is fully contained on the FC-102 quad height card. The controller is connected to the drive chassis as shown below:




FIGURE 1-1  
FD211-P SYSTEM CONFIGURATION

## 1.2 CONTROLLER CARD

The controller card is based around a 2901 microprocessor which controls all reading and writing to the disk drives and emulates DEC's RX21 (RX02) instruction set. In addition, it has the capability of completely formatting diskettes and bootstrapping the system.

This card plugs into any SPC slot in any PDP-11 backplane. A change must be made to the backplane, however. Be sure to read Section 2.3.2 on installation. A 40-conductor ribbon cable connects this card directly to each of two disk drives that are daisy-chained.

## 1.3 FD-211 DUAL DRIVE CHASSIS

This chassis holds two drives side by side, write protect switches, a circuit breaker, a power supply, and a fan.

### 1.3.1 ELECTRO-MECHANICAL

Each drive may be removed individually by removing the four machine screws that hold it in place.

Each drive has an activity LED mounted on its bezel which is lit whenever an I/O operation occurs.

### 1.3.2 POWER SUPPLIES

All systems have a power supply that generates +24 volts at 3 amps, -5 volts at 200 milliamps and +5 volts at 2 amps for the floppy disk drives.

## 1.4 SYSTEM COMPATIBILITY

The FD211 System is completely compatible with DEC's RX02 instruction set and runs with DEC supplied software or with any software designed to work with DEC's RX02 System.

## 1.5 MEDIA COMPATIBILITY

The FD211 is designed to operate with both single and double density diskettes. In single density mode, the FD211 is compatible with IBM's 3740 format. This allows interchange of media with RX01 (or FD-11) systems as well as the equipment of many other manufacturers who use this industry-standard format.

The double density mode of the FD211, while being interchangeable with RX02 systems, is a standard only to Digital Equipment Corporation. No other main-frame manufacturer uses this particular double density encoding at the present time.


### 1.5.1 DISKETTE

The flexible diskette consists of a flexible mylar disk coated with an oxide and encased in a plastic jacket. The jacket is lined with a fiber material that cleans the diskette as it rotates.

Care should be used in both selecting and handling these diskettes as described in Section 2.

### 1.5.2 SINGLE DENSITY FORMAT

In the IBM 3740 Data Entry System, each disk contains 77 tracks (0-76). Each track is divided into 26 sectors containing 128 data bytes. The organization of sectors on a track is determined logically (soft sectoring) rather than mechanically (hard sectoring). The principal characteristics of this format are shown below:



IBM TRACK FORMAT

FIGURE 1-2

The headers, each 7 bytes long, identify the track and sector being read. During normal operation, these headers are not written over. On both read and write commands, these headers will be read to identify the sector number and verify the track address.

After a gap, the data field will either be read or written.

Single density data is written using the FM encoding. Four microsecond bit cells, as shown in Figure 1-3, always contain a clock bit and also contain a data bit if a "1" is present.





1.5.3 DOUBLE DENSITY FORMAT (continued)

MARK	DENSITY	DATA BYTE HEX	CLOCK BYTE HEX	STANDARD
DATA	SINGLE	F B	C 7	IBM 3740
	DOUBLE	F D	C 7	DEC
DELETED DATA	SINGLE	F 8	C 7	IBM 3740
	DOUBLE	F 9	C 7	DEC

FIGURE 1-5

The encoding technique used in double density is different from that used in single density. It is a variation on the MFM encoding technique used by IBM and other flexible disk manufacturers. The standard MFM encoding technique consists of two microsecond bit cells with clock bits only written when there are no data bits in either the present or previous cells. The data bits are written whenever a 1 is to be written. Figure 1-6 gives an example of this.




FIGURE 1-6

As can be seen from Figure 1-6, spacings of 2, 3 and 4 microseconds between flux changes are all possible. The fact that the address marks must be written with unique patterns so as to always be distinguishable from data for a soft-sectored controller presents a special problem here. A single density address mark will be detected unwittingly if an appropriate 2 bytes of data is written in a double density data field. This danger is overcome by re-encoding a normal double density data pattern into a pattern with missing clocks. This is shown in Figure 1-7.

### 1.5.3 DOUBLE DENSITY FORMAT (continued)

WHENEVER  $D_0 D_1 D_2 D_3 D_4 D_5$  APPEARS IN A DOUBLE DENSITY  
 $0 1 1 1 1 0$  DATA FIELD,

IT IS WRITTEN AS

$D_0$	$C_1$	$D_1$	$C_2$	$D_2$	$C_3$	$D_3$	$C_4$	$D_4$	$C_5$	$D_5$
0	1	0	0	0	1	0	0	0	1	0

FIGURE 1-7

When reading double density data fields, the controller checks for a missing clock between 2 zero data cells, and if found, it substitutes in 2 ones for the 2 zero data bits.

An understanding of the format differences between single and double density described above will help the user understand the different format operations available to the user, listed in Section 5 of this manual.

### 1.5.4 CYCLIC REDUNDANCY CHECK (CRC)

Every ID and data field on the track has a pair of CRC bytes appended to it. These bytes, which are generated as the field is written, represent a cyclic permutation of all the data bits in the field, from bit 0 of the address mark to bit 7 of the last byte in the field (excluding the CRC bytes).

The cyclic permutation is the remainder that results from dividing the data bits (represented as an algebraic polynomial) by a generator polynomial  $G(X)$ . The polynomial used in the 3740 format is

$$G(X) = X^{16} + X^{12} + X^5 + 1 .$$

## 1.6 SYSTEM SPECIFICATIONS

### Capacity

Bytes per sector:	128 (SD); 256 (DD)
Sectors per track:	26
Tracks per diskette:	77
Total bytes per diskette:	256,256 (SD); 512,512 (DD)

### Access Time and Rates

Diskette to controller buffer:	32 us/byte (SD); 16 ms/byte (DD)
Buffer to CPU:	16 us/byte
Track to track:	6 ms
Seek settle time:	14 ms
Head load time:	41 ms
Rotational speed:	360 RPM +/- 2.5%
Average access (25 track seek and rotational latency):	320 ms

### Recording Technique

Method:	FM (SD); MFM Modified (DD)
Maximum bit density:	3200 BPI (SD); 6400 BPI (DD)
Track density:	48 TPI
Surfaces:	1

### Reliability

Seek error rate:	1 in $10^6$ seeks
Soft read error rate:	1 in $10^9$ bits
Hard read error rate:	1 in $10^{12}$ bits

### Environmental Restrictions

FD-211 operating range:	50 to 100 degrees F
FD-211 storage range:	32 to 150 degrees F
Diskette storage range:	50 to +125 degrees F
FD-211 humidity constraint:	10 to 80 percent without condensation

Section 2  
INSTALLATION AND OPERATION

2.1 UNPACKING

The FD-211 is shipped with all items listed on Page 1-1. The container must be opened from the top (printing on side of box reading correctly). Remove the slides, hardware, manual, and controller card from the cut-out in the top section of the packaging. By then removing this top container piece, access is gained to the drive chassis.

2.2 RACK MOUNTING THE FD-211

The FD-211 may be mounted in standard 19" relay racks using the hardware provided. The hardware consists of:

- 1 cabinet slide (right side)
- 1 cabinet slide (left side)
- 2 T-bars (rear mounting brackets)
- 4 10-32 x 1/2 flat head screws
- 12 10-32 x 1/2 pan head screws
- 10 #10 lock washers
- 6 10-32 nuts
- 2 adjustable stops

Figure 2-1 shows the proper assembly and installation of the right side cabinet slide. Using the flat head screws A and B and nuts C and D, attach the T-bar to the cabinet slide such that the notches on the end of the T-bar are towards the cabinet slide. Leave the screws loose enough to allow the T-bar to slide freely. Install adjustable stop to T-bar using flat head screw I and nut J. Leave screw loose enough to allow the stop to slide.

Slide the T-bar to its shortest position. Attach the opposite end of the cabinet slide to the front of the relay rack using pan head screws and lock washers E and F (Figure 2-1). Extend the T-bar until it touches the rear of the relay rack, position the T-bar such that its uppermost hole will align with a hole in the rear of the relay rack using pan head screws and lock washers G and H. Tighten screws A and B. Finally, check screws E, F, G, and H for tightness. This procedure is the same for the left side cabinet slide.

Before sliding the FD-211 into the relay rack, be sure that the power and ribbon cables will not interfere with the installation. From the front of the rack, place the FD-211 onto the cabinet slide. Push it fully into the relay rack and adjust the location of the adjustable stops at the rear of the FD-211 and tighten screw I. Secure the FD-211 to the stop as shown in Figure 2-2 using the remaining pan head screw and lock washers.





FIG. 2-2



CABINET SLIDE  
(RIGHT SIDE)

T-BAR  
(REAR MTG BRACKET)

FIG. 2-1

## 2.3 ELECTRICAL INSTALLATION

Next, the controller card should be installed. If a device address or interrupt vector address different from the standard DEC assignment is desired, a request must be made to CRDS for a new PROM set. In addition, any change in these assignments necessitates a change in the system software. The DEC standard assignments are given below:

Device Address:	777170
Interrupt Vector:	264

### 2.3.1 40-CONDUCTOR RIBBON CABLE

The 40-conductor grey ribbon cable should now be installed. The mating connector and the header connector on the controller board are keyed so that the connector may be inserted in only one way. The two key ways should face up when looking at the component side of the controller card (see Figure 1-1).

### 2.3.2 CONTROLLER CARD INSTALLATION

The FC-102 card provides the complete controller and interface to the Unibus in the FD-211/P floppy disk system. The FC-102 plugs into a small peripheral controller slot (SPC) of the backplane of PDP-11 series processors. Originally the "SPC" slots were designed to accommodate only those peripherals that were not DMA devices, such as serial data links. DMA peripherals were usually done on several boards occupying a complete 4-slot system unit. For this reason, the Non-Processor Grant Signal (NPG), used only for DMA, was not wired to the SPC slots on older machines. In most current machines, the NPG signal is wired to the SPC slots. However, this signal must be broken by any devices that uses DMA. All but the older PDP-11's (PDP-11/20 for example) have their SPC slots wired as shown in Figure 2-3.

#### IMPORTANT NOTE

It is necessary to break the connection between pins CA1 and CB1 on that slot of the backplane in which the user wishes to place his floppy disk controller card.

This step is necessary on all DMA peripherals that plug into SPC slots including DEC's RX02 and RL01 disk drives. The breaking of the NPG line electrically by the peripheral controller is a priority mechanism allowing the DMA device nearest the processor a preference if two DMA devices request bus mastership simultaneously.

After the user selects a slot for the FC-102 cards, he must remove the wire-wrap jumper that connects pins CA1 and CB1 on that slot. This can be accomplished with a small hand un-wire-wrap tool.



### 2.3.2 CONTROLLER CARD INSTALLATION (continued)

On older machines, the user must first disconnect pin AUI on the system unit's input Unibus connector from pin AUI on the system unit's output Unibus connector with an un-wire-wrap tool. A wire must then be connected between pin AUI on the input Unibus connector and pin CA1 on the selected SPC slot (NPG IN). Another wire should then be connected between pin CBI of the selected SPC slot and pin AUI of the system unit's output Unibus connector (NPG OUT).

If the user removes the FC-102 card from its slot at a later time, he must reconnect the jumper between pins CA1 and CBI.

Failure to make this change in the backplane will prevent the functioning of the FC-102 card as well as other peripherals on the system.

It is also important to remember when installing the FC-102 card that the BG lines must remain continuous throughout all SPC slots. No unused SPC slot may exist between the processor and the FC-102 card unless a small grant continuity card is installed in slot D of that SPC slot.

### 2.3.3 POWER CORD INSTALLATION

The line cord should now be installed. The female end of the cord goes in the oval hole (shown in Figure 2-2) in the rear of the cabinet.



## 2.4 DISKETTES

Diskettes must be treated with care to prolong diskette life and prevent damaging the sensitive recording surface. In addition we have found that not all of the media available is of good quality.

We strongly recommend that only the media listed below be used. This media has been extensively tested by Shugart, over many sample lots, and has been found to be of good quality. CRDS will only respond to complaints regarding the reliability of data stored on diskettes approved by Shugart.

	<u>IBM</u>	<u>Dysan</u>	<u>Verbatim</u>	<u>Maxell</u>
Single Density	Diskette 1	3740S	FD34-9000	FD-3200S
Double Density	-	3740D	FD34 8000	

If the user purchases single density media it will require no formatting whatsoever or single density use. The single density media may also be used for double density operation by formatting double density data fields onto the disk as described in Sections 3.4.5.1 and 5.5. We do not recommend this, however. When double density media is purchased, the media has been certified for double density use and is often given a superior oxide coating. It does not, however, have either the appropriate headers or data fields preformatted on the disk (DEC and IBM double density formats are completely different). This problem can be overcome by formatting headers onto the disk as described in Section 3.4.5.2 and then writing data fields onto the disk by either of two methods, described in Sections 3.4.5.1 and 5.5.

### 2.4.1 DISKETTE CARE

The following rules should be observed in diskette handling:

- (1) Always return a diskette to its envelope after use.
- (2) Do not place any object on top of diskettes.
- (3) Observe the storage temperature and humidity specifications of the diskettes and preferably store them at operating conditions.
- (4) Do not write on labels on the jacket above diskette surface.
- (5) Do not touch the diskette through the oval read/write aperture.
- (6) Do not store diskettes in dusty areas.
- (7) Never clean the diskette.
- (8) Never expose to prolonged heat or sunlight.
- (9) Keep away from strong magnetic fields.

#### 2.4.2 DISKETTE INSERTION AND EXTRACTION

Diskettes should be inserted into the FD-211 drives with the label up and facing the operator. The diskette should be inserted fully into the drive until it is stopped and a click is heard. The long black door handle may now be pressed down, locking the diskette in place.

The diskette is extracted by simply pressing the black button containing the red LED. The door will pop up and the diskette will pop out. It may now be removed from the drive and placed back into its storage envelope.

Diskettes may be inserted or extracted with either the power on or off. They should not be removed while in use or anytime the red activity LED is on, nor should the door be opened at this time.

#### 2.5 INITIAL OPERATION AND CHECK-OUT

The following procedure should be used after installation is completed in order to check that the system is functioning properly:

- (1) Switch the circuit breaker in the rear of the FD-211 to the up or "on" position.
- (2) Place the enable/halt switch on the processor to the halt position and turn on the processor's power switch.
- (3) Place a scratch diskette in drive 0.
- (4) Initialize the FD-211 by depositing the number 40000 in location 777170 (if the standard address assignment is used). This can be accomplished either through the use of the machine's switch register (if it has one), or ODT. Both drives should now calibrate themselves. First, unit 1 steps out 10 tracks and then steps in one track at a time until the drive indicates track 0 has been reached. This procedure is then repeated on unit 1.

At the completion of this procedure, the head on drive 0 is loaded and sector 1 of track 1 on unit 0 is read into the internal buffer on the controller card. This operation is indicated by the red activity LED on the button of the drives. First the LED on drive 1 will come on, and then the LED on drive 0. The LED on drive 0 will stay on for approximately 1/4 second after the read is completed.

If, after initializing the FD-211 controller, the red LED's do not flash on, there is a problem. The cabling should be checked as well as the power supplies.

- (5) Read the contents of the FD-211 command and status register, location 777170 (if standard assignment is used). The contents of this location should be 4040 (octal). Examining the next location, 777172, should yield the number 204 or 244. An explanation of what these bits mean can be found in Section 3.
- (6) If the above procedures work without any problem, the system should be ready for use. Diagnostics or an operating system may now be booted. For more details on bootstrapping a system, see Section 4.

## 2.6 SWITCH CONTROLS

The FD-211 contains two Write-Protect switches, and a circuit breaker as described below.

### 2.6.1 WRITE-PROTECT SWITCHES

These Write-Protect switches are two-position toggle switches that send a signal to the drive disabling the write current as well as to the controller which aborts a write operation before it is attempted and returns a status bit to the processor. These switches are very useful in protecting data from accidental destruction.

There are no special provisions in the DEC software to handle a Write-Protect violation condition. The error condition will cause the software to retry the operation several times. If the write operation is really desired, there is sometimes enough time to unprotect the disk before the retry counter runs out. This usually works but could interfere with the write operation if the switch exhibits too much contact bounce.

It should be noted that on the system disk, unexpected write operations often occur. For example, under RT11, theUSR may swap unexpectedly. The Write-Protect feature must be used with care, and should be avoided on an RT-11 system device.

### 2.6.2 CIRCUIT BREAKER

The circuit breaker may be used as a switch to turn power on and off. It is set at 4 amps for 120 volt systems and at 2 amps on 220 volt systems.

## 2.7 WRITE-PROTECT DETECTOR

In addition to the ability to write-protect diskettes by pressing a switch, a photocell and LED detect the presence or absence of a write-protect hole on the diskette. A diskette without a write-protect hole (standard IBM-supplied diskettes) will not be write-protected. However, placing a hole in the diskette as shown in Figure 2-4 will protect the diskette from being inadvertently written on. Covering this hole with opaque tape will again allow the disk to be written on. Diskettes will be write-protected if either a write-protect hole exists or if the write-protect switch is in the "protect" position. Avoid write-protecting an RT-11 system disk.





FIGURE 2-4

Section 3  
STANDARD INSTRUCTION SET

3.1 GENERAL

Program control of the FD-211 is accomplished by the proper manipulation of two device registers in the FD-211. The first of these two registers, the RXCS serves to pass control information from the CPU to the FD-211 and to report status and error information from the FD-211 to the CPU. The second register, the RXDB, transfers additional control and status information between the CPU and the FD-211. The information that is present in the RXDB at any given time is a function of the FD-211 operation that is in progress at that time.

Data transfers both to and from the diskette are always one complete sector (128 (SD) or 256 (DD) eight bit bytes) per transfer command. Partial sector transfers are not accommodated by the FD-211.

The FD-211 contains a read/write data buffer of 256 bytes. During write operations, this buffer is first loaded under a DMA command (fill) and then a write command is issued which transfers the contents of the buffer to the diskette. During read operations the read instruction is issued and the information from the proper sector and track is read into the buffer. After the buffer is full, the contents of the buffer are read out by a DMA command (EMPTY).

3.2 REGISTER AND VECTOR ADDRESSES

The normal address assignments for the FD-211 device registers and the interrupt vector address are as follows:


<u>Function</u>	<u>Address</u>
RXCS	777170
RXDB	777172
Interrupt Vector	264

3.3 FD-211 REGISTER DESCRIPTION

The 2 registers listed above are used to transfer both command and status information between the CPU and the FD-211. The first of these registers is used to initiate commands and indicate certain status information. The second of these registers has 5 different uses; which one it serves is determined by the protocol of the operation being performed. These five functions are: (1) to transfer the sector address for a read or write operation, (2) to transfer the track address for a read or write operation, (3) to indicate certain common error conditions, (4) to transfer the word count for a DMA command, and (5) to transfer the starting address of a DMA command.

### 3.3.1 RXCS COMMAND AND STATUS REGISTER (777170)

Commands to the FD-211 are initiated by loading this register with the proper function code accompanied by the "Go" bit provided that the FD-211 is not busy when the command is issued. The operation codes and bit assignments for the RSCS are shown below. Bits designated W are write only, bits designated R are read only, and bits designated R/W can be both written and read by the CPU.



#### Binary Function Code

000	Fill Buffer
001	Empty Buffer
010	Write A Sector
011	Read A Sector
100	Format Functions
101	Read Status
110	Write Deleted Data Sector
111	Read the Error Register

FIGURE 3-1

RXCS Bit Assignments and Function Codes.

### 3.3.1 RXCS COMMAND AND STATUS REGISTER ( 777170) (continued)

#### Description of Bit Assignments for RXCS

<u>Bit Number</u>	<u>Function</u>
0	<u>Go bit.</u> Initiates the selected operation in the FD-211.
1-3	<u>Function code.</u> These three bits select the operation to be performed by the FD-211.
4	<u>Unit Select Bit.</u> Selects which of two disk drives is to execute the selected operation.
5	<u>Done Bit.</u> Indicates the completion of an operation. If Interrupt Enable is set when Done is asserted, a program interrupt will occur.
6	<u>Interrupt Enable.</u> When this bit is set, the FD-211 will cause a program interrupt upon the completion of an operation.
7	<u>Transfer Request Bit.</u> This bit indicates to the CPU that the FD-211 requires data from the CPU.
8	<u>Density.</u> This bit determines the density of the function to be executed when a command is given. It is valid only when done is set at which time it indicates the density of the last command executed.
9-10	Not Used at the Present Time.
11	<u>RX02.</u> This bit indicates that a FD-211, DMA Dual Density System is on-line. It is valid at all times.
12-13	<u>Extended Address.</u> These bits determine on a DMA command the higher order address bits of the starting address. These bits allow expansion above the normal 32K addressing to 128K for this peripheral. These bits will be used with the introduction of new microcomputers to the LSI-11 family.

### 3.3.1 RXCS COMMAND AND STATUS REGISTER (777170) (continued)

#### Description of Bit Assignments for RXCS

<u>Bit Number</u>	<u>Function</u>
14	<p><u>FD-211 Initialize.</u> The FD-211 can be selectively initialized by setting this bit in the RXCS. Other devices connected to the system bus are not affected. The effects of setting this bit are the same as a bus init signal. The FD-211 will:</p> <ul style="list-style-type: none"> <li>(a) Reset Done Bit.</li> <li>(b) Move the head of drive 1 to track 0 (LED on drive will flash).</li> <li>(c) Move the head of drive 0 to track 0 (LED on drive will flash).</li> <li>(d) FD-211 clears the error and status register.</li> <li>(e) FD-211 sets Initialize Done.</li> <li>(f) FD-211 sets RXES bit 7 (DRV RDY) if drive 0 is ready.</li> <li>(g) Sector 1 of track 1 of the diskette on drive 0 is read into the buffer.</li> </ul>
15	<p><u>Error.</u> This bit indicates an error of some type occurred during a command. It is cleared by a new command or an initialize.</p>

### 3.3.2 RXDB REGISTER (777172)

As mentioned in paragraph 3.3, this register has five distinct functions determined by the protocol of the operation. Section 3-4 details this protocol. The RXDB can be read only when the FD-211 is not executing a command, the RXDB can be written only when the TR (transfer) bit (RXCS Bit 7) is set.

#### 3.3.2.1 SECTOR ADDRESS REGISTER

This register indicates which of 26 sectors, numbered 1 through 26 (32 octal), are to be used in a read or write command.




FIGURE 3-3  
Sector Address Format



### 3.3.2.2 TRACK ADDRESS REGISTER

This register indicates which of 77 tracks, numbered 0 through 76 (114 octal), are to be used in a read or write operation.




FIGURE 3-4  
Track Address Format

### 3.3.2.3 ERROR AND STATUS REGISTER

This register contains certain error and status flags for the drive selected by the unit select bit. It is always available at the completion of an operation and may also be read by the read status function.




FIGURE 3-5  
Error and Status Format

<u>Bit No.</u>	<u>Code</u>	<u>Description</u>
0	CRC	A cyclic redundancy error has occurred in a read operation.
1	X	Not used.
2	ID	Initialize DONE - indicates that an initialization took place. This can be caused by a power failure, programming or a bus signal.

### 3.3.2.3 ERROR AND STATUS REGISTER (continued)

<u>Bit No.</u>	<u>Code</u>	<u>Description</u>
3	X	Not used.
4	DEN EER	Density error. Indicates that the density of a read or write command was different than the density of the diskette in the selected drive. The read or write operation is terminated.
5	DRV DEN	This bit indicates the density of the diskette in the drive selected by a read or write operation.
6	DD	A deleted data mark was found during a read or the last command issued was a write deleted data command.
7	DRV RDY	This bit indicates that the selected drive is ready and has a diskette installed correctly. It is only valid when retrieved after a read status function or after an initialize when it indicates the status of drive 0.
8	UNIT SEL	This bit indicates which drive was selected by the last read or write operation.
9		Not Used.
10	WC OVFL	Wordcount overflow indicates that the wordcount specified by a fill or empty command was greater than sector size for the density selected. The operation is terminated.
11	NXM	Non-existent memory error. This bit is set if during a DMA transfer, the controller did not receive a reply when it attempted to read or write memory. The operation is terminated.

### 3.3.2.4 WORD COUNT REGISTER

This register indicates how many words are to be transferred in a Fill Buffer or Empty Buffer operation. The maximum word count is  $128_{10}$  for a double density sector, and  $64_{10}$  for a single density sector. This write-only register is loaded with the actual word count and not the 2's complement.




FIGURE 3-6  
Word Count Format

### 3.3.2.5 BUS ADDRESS REGISTER

This 16-bit, write-only register indicates the starting bus address of data transferred during Fill Buffer, Empty Buffer, and Read Error Register operations.




FIGURE 3-7  
Bus Address Format

### 3.4 COMMAND FUNCTIONS AND THEIR PROTOCOL

The function codes listed in Figure 3-1 are described in detail below. The specified protocol of each function must be observed or data loss may result.

#### 3.4.1 FILL BUFFER FUNCTION (000)

This function is used to fill the FD-211 internal buffer with data from the memory. The contents of the buffer are usually written onto the disk after completion of this operation. The following procedure is used in executing this function:

- (1) Store function code 000 and the Go bit into the RXCS (777170).
- (2) Check that the TR bit in the RXCS is on.
- (3) Deposit the wordcount in the RXDB register (777172).  
This number will be 100 (Octal) for a full single density sector and 200 (Octal) for a full double density sector. Wordcounts less than these numbers are permissible for partial sector transfers. The remainder of the buffer will be set to 0.
- (4) Again, check that the TR bit in the RXCS is on.
- (5) Deposit the starting address in the RXDB register.  
This address may be anywhere in the 30K memory address range of the PDP-11. For addressing above 32K, set the extended address bits in the RXCS during step 1 (see Section 3.3.1).
- (6) The controller will perform DMA read operations on memory to obtain up to 128 16-bit words of memory (double density or up to 64 words single density).
- (7) The Done bit will then be set and the function is complete.

#### 3.4.2 EMPTY BUFFER ROUTINE (001)

This function is used to empty the FD-211 internal buffer into the CPU.

This function is usually performed after the completion of a read operation. The following procedure is used in executing this function.

- (1) Store function code 001 and the Go bit into RXCS.
- (2) Check that the TR bit in the RXCS is on.
- (3) Deposit the wordcount in the RXDB register (777172).  
This number will be 100 (octal) for a full single density sector and 200 (octal) for a full double density sector. Wordcounts less than these numbers are permissible for partial sector transfers.
- (4) Again, check that the TR bit in the RXCS is on.
- (5) Deposit the starting address in the RXDB register. This address may be anywhere in the 30K memory address range of the PDP-11. For addressing above 32K, set the extended address bits in during step 1 (see Section 3.3.1).

#### 3.4.2 EMPTY BUFFER ROUTINE (001) (continued)

- (6) The controller will perform DMA write operations on memory to unload up to 128 16-bit words (double density or up to 64 words single density).
- (7) The Done bit will then be set and the operation is complete.

#### 3.4.3 WRITE SECTOR FUNCTION (010)

This function is used to write the contents of the FD-211's internal buffer onto the disk. The following procedure is used in executing this instruction.

- (1) Store function code 010 and the Co bit into RXCS. The setting of the density bit will determine if a single or double density operation is to be performed.
- (2) Check that the TR bit in the RXCS is on.
- (3) Now transfer the sector address to the FD-211 via the RXDB.
- (4) Check that the TR bit in the RXCS is on.
- (5) Now transfer the track address to the FD-211 via the RXDB.
- (6) A write operation will now occur if no error conditions appear. Write protection is sensed and the operation terminated if set. Any track seeking required now takes place. If the head of the selected unit was loaded at the time the operation was initiated, then there can be no danger of a density error and the write operation is performed. If the head was unloaded at the time the operation was initiated the diskette may have been changed. The controller, therefore, performs a quick density check of the next sector to come, lasting on the average only 4 to 5 milliseconds. If the density of the operation agrees with the density of the diskette, the write operation is performed.
- (7) On completion of the operation, the Done bit will be set and the RXDB will contain the error and status register.

#### 3.4.4 READ SECTOR FUNCTION (011)

This function is used to read a diskette sector into the FD-211's internal buffer. The procedure followed by this function is identical to that of the write sector function described in the previous paragraph. After waiting for the TR bit each time, the sector address and then the track address are deposited into the RXDB, location 777172. The function is then executed.

#### 3.4.5 FORMAT FUNCTION (100)

Two separate and distinct format functions are provided with the FD-211 system.

### 3.4.5.1 FORMAT DATA FIELDS

The first of these is identical to DEC's "Set Media Density" operation. It rewrites the data fields of all sectors on a diskette with either single or double density marks, as specified by bit 8 (density bit) in the command register. These marks are in fact always rewritten during any write operation but the write operation does not allow the user to write a mark with a density different from other marks on the diskette (see write function, Section 3.4.3). This is to prevent diverse densities on one diskette.

Therefore, in order to change the density of a diskette, all data field marks must be rewritten to the new density. This operation will destroy all data on the diskette, leaving data fields of all zeros. The location of these data field marks is shown in figure 1-2.

The format function can be performed by using the format command under RT-11 (see Section 5) or directly through the use of ODT. This is done by the following sequence of operations:

- (1) Store function code 100, the Go bit, the density bit (0 for single density, 1 for double density) and the unit select bit into RXCS. The possible combinations of bits are listed below.

Format	Code
Unit 0, single density	11
Unit 0, double density	411
Unit 1, single density	31
Unit 1, double density	431

- (2) Wait for the trans bit to be set.
- (3) Deposit the key word 111 (octal) into the RXDB. This key word is to help prevent accidental initiation of this function.
- (4) The FD-211 will start the selected drive at track 0, sector 1 and rewrite all sectors through track 76, sector 26. If the operation is interrupted at any time during the 25 seconds needed to complete this operation, the operation must be restarted and allowed to complete, otherwise an "illegal" diskette has been created.
- (5) If the operation does not complete normally, and ends with the error flag on, a difficulty was encountered in reading the headers of the sectors. This may be due to defective media. The user may attempt to rewrite these headers using the instructions given in Section 3.4.5.2.
- (6) If the operation completes successfully, the Done bit will be set and no error condition will be flagged.

### 3.4.5.2 FORMAT HEADERS

Although it is possible to buy diskettes preformatted with the standard IBM 3740 headers, these diskettes are intended for single density, not double density operation. These diskettes have not been certified for double density, and in some cases they lack the superior oxide coating that diskette manufacturers place on double density media. It is therefore suggested that the user purchase double-density certified media. Because no other mainframe manufacturer besides DEC uses a single density header format for double density operation, at the present time diskette suppliers do not supply double density media with formats compatible with the FD-211 and the RX02.

In case of the RX02, this media is unusable. However, the FD-211 provides a function to write headers. These headers are never written by the RX02 and only written by the FD-211 during this format operation.

This format function cannot be activated from RT-11 but can easily be activated through ODT.

- (1) Store the function code 100, the Go bit and the unit select bit into RXCS.

Format the headers of the diskette in unit 0: 11  
Format the headers of the diskette in Unit 1: 31

This is accomplished by depositing either 11 or 31 into 777170 by using ODT or the processor's switch register (if available).

- (2) The key word is now used to avoid accidental initiation of this function. It also differentiates this function from the format data field's function. The key word is 1111 (octal) and should be deposited in the RXDB (777172).
- (3) This operation takes approximately 25 seconds to complete. If interrupted, it must be reinitiated or an "illegal" diskette will have been created. This routine does not format the data fields. At the completion of this function, the user must write either single or double density data fields using the other format function described in Section 3.4.5.1. The disk is unusable until this is accomplished.

### 3.4.6 READ STATUS FUNCTION (101)

When this function is executed the error and status register will be loaded into the RXDB. This register will contain the same status generated from the last operation except that bit 7 will now indicate whether the drive selected by the unit select bit is ready or not.

### 3.4.7 WRITE SECTOR WITH DELETED DATA FUNCTION (110)

This function is identical to the write sector function described in paragraph 3.4.3 except that a deleted data marks is written just before the start of the data field.

### 3.4.8 READ ERROR CODE (111)

This function is used after an error occurs to determine the exact nature of the error and the contents of certain registers at the time the error occurred. It is initiated by the following sequence:

- (1) Deposit the Go bit and the function code 111 (17) into the RXCS.
- (2) Wait for the trans bit in the RXCS to set.
- (3) Deposit the starting address of an unused 4 word block in memory into the RXDB.
- (4) The FD-211 will now DMA the following words into memory (LSB = least significant byte, MSB = most significant byte):

Definitive error code	Word 0, LSB
Word count register	Word 0, MSB
Current track address of drive 0	Word 1, LSB
Current track address of drive 1	Word 1, MSB
Target track of command	Word 2, LSB
Target sector of command	Word 2, MSB

It should be noted that the word count register is only valid after DMA commands and that the target track and sector registers are only valid after disk I/O commands.

The definitive error codes given by the FD-211 are defined below:

Octal Code	Error Code Meaning
0010	Drive 0 failed to see home on Initialize.
0020	Drive 1 failed to see home on Initialize.
0100	Write protect violation attempted.
0120	A preamble could not be found or no ID mark found within allowable time span.
0150	The header track address of a good header does not compare with the desired track.
0160	Too many tries for header identification routine.
0170	Data AM not found in allotted time.
0200	CRC error on reading the sector from the disk.
0230	Word count overflow.
0240	Density error.
0250	Wrong key word for set media density command.



Section 4

SPECIAL FUNCTIONS: BOOTSTRAP AND SELF-TEST

The FD-211 has the ability to bootstrap system and diagnostic diskettes without the aid of a separate bootstrap card.

4.1 ENABLING AND DISABLING THE BOOTSTRAP

The bootstrap feature may be enabled or disabled by means of a jumper J3 on the card as shown in Figure 4-1.




FIGURE 4-1

All cards are shipped with the jumper installed, that is, the boot enabled.

#### 4.2 USING THE BOOTSTRAP

A bootstrap ROM is provided on the FC-102 so that the user may bootstrap a system or diagnostic diskette if desired. This bootstrap occupies addresses 775000 through 775376 which is not the normal bootstrap address range. This was done to allow users that already have bootstraps at the normal bootstrap address (starting at 773000) to use those bootstraps at the same time. Bootstraps are built into all PDP-11/04 and PDP-11/34 processors. These bootstraps ROM's also contain a small diagnostic, ODT, and bootstraps for a variety of devices. It would unreasonably limit the user not to be able to use this ROM and for that reason CRDS has assigned its bootstrap ROM to another address.

The address range selected interferes with the standard address assignments of the DM11, DN11 and DV11. All of these devices are 16-line communication interfaces and are unlikely to be used on a small system that uses a floppy disk as its system device.

However, if for some reason any of the addresses 775000 through 775376 are used, the bootstrap can be disabled as shown in Section 4.1. If the user needs to boot from floppy disk, then he must get a current bootstrap ROM set for his PDP-11/04 or PDP-11/34 which includes the DY (RX02) bootstrap code. At this writing, most machines do not contain this code. On other PDP-11 machines, a separate bootstrap card could be used.

Most users, however, will find the existence of our bootstrap at a non-standard address advantageous in that it does not interfere with DEC bootstrap ROM's which are far more common than 16-line communications equipment on PDP-11's.

To boot a diskette, simply start execution of the processor at location 775000 with a bootable disk in drive 0 of the FD211. Start at address 775006 if you desire to boot on drive 1. The chart below shows the possible starting addresses. A PDP-11 processor may be started at these locations by either its switch register (if available) or by using ODT.

	PDP-11 with MMU Start at	PDP-11 without MMU Start at
Boot on Drive 0	775000	775000
Boot on Drive 1	775006	775006

### 4.3 SELF-TEST FUNCTION

This function may be used to both diagnose problems with the FD-211 system as well as to certify that all sectors of a particular diskette are readable. When initiated, this function starts reading each sector of the diskette starting with track 0, sector 1 and ending with track 76, sector 26. If at any time a CRC or other error is encountered, this microcode routine will halt with the error and done bits set. If no error is found, a halt occurs after reading track 76, sector 26 and the done bit is set. The function is initiated in the following manner.

- (1) Store function code 100, the GO bit, the density bit (0 for single density, 1 for double density) and the unit select bit into RXCS (177170). The possible combinations of bits are listed below.

<u>Format</u>	<u>Code</u>
Unit 0, single density	11
Unit 0, double density	411
Unit 1, single density	31
Unit 1, double density	431

- (2) Wait for the trans bit to be set.
- (3) Deposit the key word 2111 (octal) into the RXDB (777172).
- (4) The FD-211 will start the selected drive at track 0, sector 1 and read all sectors through track 76, sector 26.
- (5) If the operation does not complete normally, and ends with the error flag on, a difficulty was encountered in reading one of the sectors. This may be due to defective media.
- (6) If the operation completes successfully, the Done bit will be set and no error condition will be flagged.

## Section 5

### USE OF THE FD-211 WITH RT-11

The introduction of new products in the computer industry often brings questions from users on compatibility with previous equipment, software, and media. This product is no exception.

The FD-211 (and the RX02) is compatible with single density media but has a different instruction set than its predecessor, the FD-11 (and RX01). This has led to much confusion. The FD-211 allows the user access to all of his old single density programs, the ability to store twice as much data in double density mode, and the use of DMA to transfer data to and from the disk.

The FD-211 (and the RX02) does, however, require a different handler than the single density systems. This handler utilizes DMA to transfer data rather than using program-controlled data transfers. This handler is available in RT-11-V03B and later software revisions. From the point of view of the operating system, the FD-211 is a new device designated "DY". The single density system designation for floppy disk is "DX".

The new handler does have one unusual feature. It will read both single and double density disks without any need for the user to tell the system which density disk it is using. A difference in the format of the diskette's data field automatically informs the handler of the density of the disk. Both single and double density disks are designated "DY".

#### 5.1 GENERATION OF DY-COMPATIBLE RT-11 SYSTEM DISKS

In order to use RT-11 with the FD-211 (or the RX02), it is necessary to have or generate a system with a DY monitor built in rather than a DX monitor. The easiest option for the user is to obtain his RT-11 system on double density media. CRDS supplies such a diskette when RT-11 is purchased along with the MF-211. The system will then already have the DY monitor built in. The diskette can be placed in drive 0 and will boot with an init as described in Section 4.

Many users, however, have RT-11 system distribution media in single density format with a DX monitor built into the system. These diskettes have to be rebuilt to boot on an FD-211 (or RX02). In order to build a DY-based system, access to an FD-11 or an RX01 is required. If none is available, a DY-based monitor system diskette must be obtained.

#### 5.2 CREATING A DY-BASED SYSTEM ON A DX-BASED SYSTEM

The DX-based system disk has a system monitor file on it: either DXMNSJ, DXMNFB, or DXMNXM. (It may have more than one of these, but you are only using one. If you don't know which one you are using, boot the system. The first thing printed on the terminal will be either RT-11SJ, RT-11FB, or RT-11XM. The last two letters of that are the same as the last two letters of the monitor you are using.) This system monitor file is written for use with single density systems.

## 5.2 CREATING A DY-BASED SYSTEM ON AN FD-11 (continued)

The system disk you are now using also has a bootstrap program on it. It is not accessible as a file (you won't see it in the directory for instance) but it is there nonetheless. This bootstrap is also written for single density systems. Everything else on your system disk is compatible with double density systems (unless you have put something unusual on it).

To generate a DY-based system diskette, you must create a system disk identical to the first, except that it will have a version of the monitor and the bootstrap written for use on a double density system. (This new disk is still single density - it is not the one you will be using on your double density system, but is a step to creating that one.)

If a SYSGEN was done to create your current system disk, you must do another SYSGEN to create a new (still single density) system disk equivalent to the first. (If you don't know whether a SYSGEN was done, bring up the system. If the first thing it types out has an "(S)" in it (for example, RT-11SJ (S)V03-00), then SYSGEN was done.) While doing the SYSGEN, the program will ask you "What is the name of the system device?" Tell it DY. See the RT-11 SYSTEM GENERATION MANUAL for further details.

If a SYSGEN was not done to create your current system disk, that means that the monitor file was used just as it appeared on one of the distribution disks. Also on one of the distribution disks (disk 5/8, probably) is a version of the monitor written for double density systems. Its name is DYMNSJ if you are currently using DXMNSJ, and is DYMNFB if you are using DXMNFB. (DXMNXM is created with a SYSGEN.) To create the new (still single density) system disk, do the following:

Bring up your DX-based system in the usual way.

Insert a blank disk in drive 1 and initialize it:  
.INIT/NOQUERY DX1:

Copy SWAP.SYS (the most used file) onto it first:  
.COPY/SYS DX0:SWAP.SYS DX1:\*,\*

Prepare to copy the new monitor onto it:  
.R PIP

Replace the system disk in drive 0 with distribution disk 5/8 (the one with the double density monitor on it) and copy the monitor onto the new disk:

\*DX1:\*,\* = DX0:DYMNSJ.SYS/Y  
or  
\*DX1:\*,\* = DX0:DYMNFB.SYS/Y

Put the system disk back in drive 0 and return to the monitor  
\*↑C

Copy the rest of the system disk, excluding the old monitor:

.COPY/SYS/EXCLUDE DX0:DXMNSJ.SYS DX1:\*,\*  
or  
.COPY/SYS/EXCLUDE DX0:DXMNFB.SYS DX1:\*,\*

Finally, install the new bootstrap:

.COPY/BOOT DX1:DYMNSJ.SYS DX1:  
or  
.COPY/BOOT DX1:DYMNFB.SYS DX1:

If any patches had been made to DXMNSJ (or DXMNFB) they should also be made to DYMNSJ (or DYMNFB).

### 5.3 CREATING A DY-BASED DOUBLE DENSITY SYSTEM DISKETTE

The diskette created by the instructions in paragraph 5.2 is a DY-based single density system diskette. In order to create a double density DY-based system diskette, the single density diskette must be booted on the FD-211 system and copied to a double density diskette.

The single density DY-based system diskette is easily bootable in the exact same way as a double-density DY-based diskette as described in Section 4.

Now that the system is booted, put a blank double density disk in drive 1. (The term double density diskette refers to a diskette that has been formatted with double density data field marks. See Section 2.4 on how to make a double density diskette.) Then execute the following sequence:

Initialize the disk in drive 1:

```
.INIT/NOQUERY DY1:
```

Copy the system disk onto it:

```
.COPY/SYS DY0:*. * DY1:*. *
```

Load the bootstrap block:

```
.COPY/BOOT DY1:DYMNSJ.SYS DY1:
```

or

```
.COPY/BOOT DY1:DYMNFB.SYS DY1:
```

The disk in drive 1 should now boot if you put it in drive 0 and follow the normal bootstrap procedure.

You can use any single or double density disks as user disks with this double density disk as the system disk. All system programs should run, and any user programs that don't expect an RX01 on the system should run (i.e., programs that don't reference files with "DX0:" as part of the file name and that don't reference 177170 expecting to find an RX01 there, should run).

### 5.4 USING THE FORMAT COMMAND UNDER RT-11

In order to format the data fields of a diskette, an RT-11 utility program called FORMAT may be used. In order to use this utility, type:

```
.R FORMAT <CR>
```

The program will type an asterisk, after which the user should type the device name, either DY0: or DY1:.

```
*DY0: <CR>
```

After checking to be sure you wish to do this (the format operation, of course, destroys all data), the drive specified will write double density data fields on all sectors of the diskette. If you wish to format the diskette to be single density, type DY0:/S instead.

#### 5.4 USING THE FORMAT COMMAND UNDER RT-11 (continued)

If the operation is interrupted, it should be restarted or an "illegal" diskette of mixed densities will be created. If the operation fails to complete successfully, a problem was encountered in reading the headers of the diskette. The user may attempt to reformat these headers by the procedure given in Section 3.4.5.2. This feature is an additional feature offered by CRDS but not by DEC, therefore it is not contained in RT-11's format utility program.

## Section 6

### UPDATING FD-11 SYSTEMS TO DOUBLE DENSITY DMA OPERATION

#### 6.1 INSTALLATION

Those users who own FD-11 systems may update their systems to FD-211 by replacing their FD-11-100 controller cards with the new FC-102 controller card. The 10-1/2 inch FD-11 dual drive chassis may be used with the FC-102 controller card if the procedure below is followed.

##### 6.1.1 POWER CONSIDERATIONS

Some older dual-drive chassis FD-11 do not contain +5 volt power capability. Units shipped prior to April 1978 will not have this capability unless the optional +5 volt power supply was purchased. This may be checked by opening the chassis and examining the power supply(s). Those that contain a Power-One power supply (silver in color) will operate without any power supply modification. Those units that contain two Elexon (black) power supplies require no modification. Those units, though, that contain only one Elexon power supply must be equipped with an additional power supply and the FD-11 must be returned to CRDS for the installation of a new power supply.

##### 6.1.2 CABLING

The six-conductor power cable used in FD-11 systems is no longer required and should be set aside. The grey or red 50-conductor ribbon cable is also no longer required and should be set aside. The FD-211-U-P (FD-11 update kit) should contain one FC-102 controller card and a grey cable with two 50-conductor edge connectors and a 40-conductor header. This cable was designed for the FD-211 5-1/4 inch chassis but may be used with older FD-11 10-1/2 inch chassis as well. The cable should be installed so that looking at the rear of the FD-11 chassis, the red stripe of the cable should be on the right. The end 50-conductor connector will then attach to the bottom drive and the middle connector to the top drive as shown in Figure 6-1. The other end of the cable (the 40-pin header) is installed as shown in Figure 1-1 and described in paragraph 2.3.1.






FIGURE 6-1

## 6.2 USE OF THE FD-211-U-P

The system is now functionally equivalent to a standard FD-211-P system. The only difference exists in the unit select switches. Either one may be set to 0 and the other to 1. No use of the other numbers (2-9) is made. Other sections of this manual should now be consulted for information on use.

Section 7  
MAINTENANCE

This section contains the basic maintenance information on the FD-211 needed to service the system by spare parts. It is suggested that only large volume users of the FD-211 attempt to service the system to the component level. It is far better for the majority of users to swap out either a card or a drive in the event of a failure. We have included here the diagnostic and maintenance procedures necessary to do this.

7.1 PREVENTIVE MAINTENANCE

Though the cards and other electronics require no preventive maintenance, all mechanical devices do. Preventive maintenance of the disk drive, however, is minimal due to the efficient design, reliability, and manner in which the unit is operated.

7.1.1 VISUAL INSPECTION

During normal operating conditions, periodically inspect the unit for signs of dirt, wear, or loose latching hardware on the handle. When servicing the unit, check all areas for signs of loose connections, abnormal wear, and dirt accumulation on the flexible disk guide.

7.1.2 CLEANLINESS

A clean disk drive, externally and internally, will extend the operating life of the equipment and enhance the appearance. The importance of periodic visual inspection and normal cleanliness of the unit cannot be over-emphasized.

7.1.3 ROUTINE MAINTENANCE SCHEDULE

A systematic routine operating check is recommended. The checks should be performed in accordance with Figure 7-1.

FIGURE 7-1  
ROUTINE MAINTENANCE SCHEDULE

UNIT	FREQ MONTHS	CLEAN	OBSERVE
Read/Write Head	12	Clean Read/Write Head ONLY IF NECESSARY	Oxide build up
R/W Head Load Button	12*	Replace	
Stepper Motor and Lead Screw	12 12	Clean off all oil, dust, and dirt	Inspect for nicks and burrs
Belt	12		Frayed or weakened areas
Base	12	Clean base	Inspect for loose screws, connectors, and switches
Read/Write Head	12		Check for proper alignment

## 7.2 DIAGNOSING THE PROBLEM

There are really only two basic elements in the FD-211: the controller card and the drives. It is most important to isolate the problem to one of these two elements. The only other possible problems are the power supply, switches, and cabling. The following procedures may be used to isolate a problem.

First refer to Section 7.2.1. This section lists some common problems with FD-211 systems. If this does not help, check the power supply (Section 7.2.2) and run the diagnostics (Sections 7.2.3 and 7.2.4).

### 7.2.1 COMMON PROBLEMS

<u>Problem</u>	<u>Possible Cause</u>	<u>Remedy</u>
LED on drive "0" stays on, run LED is off, no terminal response (when booting)	No disk in drive "0" DMA chain broken No double density boot on diskette	Insert Diskette Check card placement  Replace diskette
Processor is in ODT, run LED is off, LED's on drives flash once (when booting)	Interrupt chain broken Halt/Enable switch in halt position Processor is not strapped to come up in mode 2	Check card placement Switch to run  See Section 4.2
Many retries on a write	Diskette is write protected Bad diskette (headers not readable) Head dirty Worn load pad	Write enable the diskette Try a /K in DUP  Check, clean Check, replace
Many retries on a read	Bad Diskette Head dirty Worn load pad	Try a /K in DUP Check, clean Check, replace

### 7.2.2 POWER SUPPLY

The FD-211 power supply provides three voltage levels: +24 volts, +5 volts, and -5 volts. These voltages are bussed by yellow, orange, and blue wires respectively. Green wire is used for ground. The outputs of the supply are marked and may be easily tested with a voltmeter. Below each output is a pot which adjusts the voltages. If the voltages are off more than 5%, try to bring them back into spec with these pots.

To replace the power supply, it is easiest to disconnect the power connectors at the drive and the AC terminal block, thereby removing the supply with the harness. CRDS provides spare power supplies with the harness attached making replacement easier.

### 7.2.3 FD-211 DIAGNOSTIC

Several useful diagnostics are available to the user. The simplest one is built into the microcode of the FC-102 controller. Place a good diskette into drive 0 and init the system with the halt switch in the halt mode. Examine location 777170 using ODT. If the error bit, bit 15 is set, the nature of the error can be determined by looking at location 777172 for simple errors, and performing the read error code function for other errors as described in Section 3.4.8.

For problems that are not solid, the self-test function as described in Section 4.4 should be performed. Try to isolate the problem to a single drive or the media.

For more difficult problems, the DEC diagnostic ZRXDA is suggested.

### 7.2.4 ZRXDA DIAGNOSTIC

This diagnostic will provide a thorough test of the FD-211 system. The diagnostic may be loaded from diskette. The diagnostic provides many modes, selectable by the user, in which to test the FD-211. This diagnostic is especially useful for testing data reliability.

120, 160, or 200 (CRC) errors are often caused by defective media, drive or read/write circuitry on the controller card. Try to isolate the problem to either the media or a single drive. Other error messages usually indicate a faulty controller card.

### 7.2.5 DRIVE REPLACEMENT

Problems with a single drive in a dual drive system usually indicate a problem in the failing drive, rather than the controller. If the problem can be isolated to one drive, the drive should be removed for repair or replacement. The remaining drive can be configured to respond as drive 0 or drive 1 (see Section 7.2.5.1). Follow the procedure outlined below to remove drives:

- (1) Remove the 50-pin ribbon cable edge connector from the drive.
- (2) Unplug the 3-terminal AC power connector from the drive.
- (3) Unplug the 6-terminal DC power connector from the drive.
- (4) Remove the two screws that hold the drive in place from the bottom of the unit.
- (5) Remove the two screws that hold the drive in place from the side of the unit.
- (6) Slide the unit backwards one inch so that the write-protect switch clears its hold in the front panel.
- (7) Remove the drive by pulling it up out of the chassis.
- (8) A replacement drive may be installed by reversing the above procedures. The proper jumper configuration of such a drive is given below.

#### 7.2.5.1 DRIVE CONFIGURATION

The Shugart SA-800R drive contains a PC card with silk screen designations for various jumpers. There are two differences between the jumper configuration in the FD-211 and the standard configurations used by Shugart.

- (1) The jumper marked HL is moved to DS.
- (2) The jumper marked DS1 is removed. If one wishes the drive to respond as unit 0, place this jumper at DS3. For response as unit 1, the jumper should be placed at DS4.
- (3) The write protect switch is wired between Test Point 25 and VCC (see Figure 7-2).

#### 7.2.6 FC-102 CONTROLLER CARD REPLACEMENT

The controller card consists of a 6 MHz bipolar bit slice microprocessor that controls almost all functions performed by the controller. DMA bus cycles, reading and writing of the disk, and RX02 instruction set emulations are handled by this processor. The few functions in hard logic include DMA grant arbitration, interrupt acknowledge arbitration, and the phase-locked loop, used to track data from the disk on read operations.

The phase-locked loop is the only analog circuitry on the board and contains an inductor and capacitor to isolate the VCO chip from the digital logic. The effective isolation may be checked by placing a scope on Z61 pin 16, AC coupled. There should be less than 30 millivolts of noise. Other checks that may be made on this circuitry are listed below. These checks should be performed when the reliability of reading data is in questions.

- (1) Check the single density bit cell divider one-shot at Test Point 5 (Z64 pin 12). During read operations, this one-shot will be triggered and using a scope set on negative-edge triggering, the one-shot should stay low for 1000 +/- nanoseconds.
- (2) Check the double density bit cell divider one-shot at Test Point 6 (Z64 pin 4). During read operations this one-shot will be triggered and using a scope set on negative-edge triggering, the one-shot should stay low for 500 +/- 20 nanoseconds.
- (3) Check the voltage level of Test Point 2 (Z61 pin 2) with a digital voltmeter while the FD-211 is idle. It should read 3.0 +/- 0.3 volts DC.

The FC-102 controller card should be swapped first when trying to isolate any problem that does not appear to be drive dependent or media dependent, or if it fails any of the above tests. Turn off the power, remove the card, and inspect it for contaminated gold fingers or any contaminants that might have caused a short. If the card is still not working, it should be returned to CRDS.




FIGURE 7-2

## RETURNING MATERIAL

IN THE EVENT THAT IT BECOMES NECESSARY FOR YOU TO RETURN MATERIAL TO CHARLES RIVER DATA SYSTEMS, PLEASE:

1. Phone the factory in advance of your return  
When you call, please have available:
  - a. A description of the problem or reason for the return.
  - b. The serial number of the unit.
  - c. Your original purchase order number, CRDS invoice number, or shipping memo number
- 2 Obtain a Return Authorization (RA) Number from CRDS.
3. Show the RA Number on all packages shipped to CRDS.  
Parcels which are not marked with an RA Number may be refused at the factory. You should reference this number in all communications concerning the returned goods.
4. Enclose a description of the problem or any other information which may help in expediting repair of the unit.

Please note that a new purchase order number will be required whether the unit is in warranty or out of warranty.

## WARRANTY


### CHARLES RIVER DATA SYSTEMS, INC.

All equipment purchased directly from CRDS, its authorized representatives and/or franchised distributors is warranted on "return-to-factory" basis against defects in workmanship and materials under normal and proper use in its unmodified condition for a period of ninety (90) days from date of initial shipment. As a condition of this warranty, Customer must (a) obtain a CRDS Return Authorization (RA) Number, (b) ship the equipment (or sub-assembly) to the designated CRDS repair point, transportation prepaid, and (c) include with the returned equipment (or sub-assembly) a WRITTEN description of the claimed defect. Transportation charges for the return to Customer of in-warranty repaired equipment (or sub-assembly) shall be paid by CRDS within the fifty (50) United States, District of Columbia, and Canada. Returns to customer of out-of-warranty repaired equipment (or sub-assembly) shall be "Transportation Collect". If CRDS determines that the equipment (or sub-assembly) returned to it for warranty correction is not defective as herein defined, Customer shall pay CRDS all costs of handling and transportation. All repaired or replaced equipment shall be returned only to Customer and not to third parties to whom Customer may have sold, leased or otherwise transferred the equipment. The warranties provided herein are exclusive to the Customer only.

Charles River Data Systems, Inc., hereby warrants all equipments (or sub-assemblies) of first party manufacturers and/or their authorized, franchised representatives and distributors against defects in workmanship and materials, only to the full limits and extent that such items are warranted to CRDS.

This warranty is expressed in lieu of all other merchantability warranties expressed or implied (including the implied warranty of fitness for a particular purpose) and of all other obligations or liabilities on CRDS's part, and CRDS neither assumes nor authorizes any other person to assume any other liabilities in connection with the sale of the said article.





VOLTAGE-COLOR CODE	
+24	YELLOW
+5	ORANGE
GND	GREEN
-5	BLUE
110/220 HOT	BLACK
110 NEUTRAL	WHITE
220 HOT	

FD 211/311/411 WIRING SCHEMATIC

